

First use and cleaning of Tava amphoras.



Before leaving the warehouse, the amphoras has passed a 48 hours leakproofness test. We ask you to repeat the test once the amphora arrives in your winery to ensure any possible damage caused by transportation. If you identify any

kind of anomaly, please, contact our office. We will provide an appropriate replacement.

Before first use, we recommend you to rinse the amphora with plenty of water to remove dust and dirt usually due to its transport and storage.

FIRST USE

Rinse the amphora with plenty of water.

CLEANING

TAVA amphoras were designed to make the cleaning operations easy and efficient. You can use:

- Acid cleaners;
- Basic products (detergents);
- High temperature (not recommended in case of metal parts present).

STORAGE

If the amphora should be left empty for a while, we recommend complete drying after the washing procedure.

***For subsequent washes see the
cleaning and sanitizing protocol
with Melyo.***

